



UNDERDRIVE PLANETARY GEAR

COMPONENTS




DISASSEMBLY

1. REMOVE UNDERDRIVE PLANETARY GEAR PRELOAD (See page [AX-240](#))



2. REMOVE UNDERDRIVE INPUT SHAFT NUT SST 09930-00010 (09931-00010, 09931-00020), 09387-00050, 09564-16020


(a) Using SST, loosen the staked part of the nut.



(b) Clamp the underdrive planetary gear in soft jaw vise.

NOTICE:

Be careful not to damage the differential drive pinion.





(c) Using SST, remove the lock nut.
SST 09387-00050

3. REMOVE CYLINDRICAL ROLLER BEARING INNER RACE

(a) Using SST, remove the cylindrical roller bearing race inner.

SST 09950-00020, 09950-00030, 09950-60010
(09951-00340)






4. REMOVE UNDERDRIVE PLANETARY GEAR ASSEMBLY

- (a) Using SST and a press, remove the differential drive pinion, parking lock gear, counter driven gear with underdrive planetary ring gear and front tapered roller bearing.


SST 09387-00050



- (b) Clamp the underdrive planetary gear in soft jaw vise.


- (c) Using SST, remove the rear tapped roller bearing from the underdrive planetary gear.

SST 09950-00020, 09950-00030, 09950-60010 (09951-00340)



5. REMOVE UNDERDRIVE PLANETARY RING GEAR

- (a) Using snap ring pliers, remove the snap ring.




- (b) Remove the underdrive planetary ring gear from the counter driven gear.


INSPECTION

1. INSPECT UNDERDRIVE PLANETARY GEAR PRELOAD

- (a) Using SST, fix the underdrive planetary gear.

SST 09387-00050







- (b) Using SST and a torque wrench, measure the turning torque of the underdrive planetary gear in place while rotating the torque wrench at 60 rpm.
SST 09387-00050
Torque: Turning torque at 60 rpm
0.10 to 4.41 N*m (1.0 to 45 kgf*cm, 0.9 to 39 in.*lbf)

HINT:


Use a torque wrench with a fulcrum length of 160 mm (6.3 in.)

REASSEMBLY**1. INSTALL UNDERDRIVE PLANETARY RING GEAR**


- (a) Install a new snap ring to the outer race of the tapered roller bearing.




- (b) Using a piston ring compressor, squeeze the snap ring.



- (c) Using SST a press, press in the outer race of the tapered roller bearing.
SST 09950-60020 (09951-00890), 09950-70010 (09951-07100)



- (d) Install the underdrive planetary ring gear to the counter driven gear.




(e) Using snap ring pliers, install the snap ring.

2. INSTALL UNDERDRIVE PLANETARY GEAR ASSEMBLY


(a) Using a press, press in the rear tapered roller bearing to the underdrive planetary gear.

NOTICE:

Press in the bearing until it becomes flat at the bottom



(b) Install the counter driven gear with planetary ring gear to the underdrive planetary gear.




(c) Using SST and a press, press in the front tapered roller bearing.

SST 09214-76011

NOTICE:


Press in the counter driven gear while rotating it.




(d) Using a press, press in the parking lock gear.


NOTICE:

Press in the counter driven gear while rotating it.






- (e) Using a press, press in the differential drive pinion.
NOTICE:
Press in the counter driven gear while rotating it.




3. INSTALL CYLINDRICAL ROLLER BEARING INNER RACE

- (a) Using a press, press in the cylindrical roller bearing race inner.
NOTICE:
Press in the counter driven gear while rotating it.




4. INSTALL UNDERDRIVE INPUT SHAFT NUT

- (a) Clamp the underdrive planetary gear in a soft jaw vise.
NOTICE:
Be careful not to damage the differential drive pinion.
 (b) Using a socket wrench, install a new lock nut.
Torque: 280 N*m (2,855 kgf*cm, 207 in.*lbf)
HINT:
 Use a torque wrench with a fulcrum length of 750 mm (29.53 in.)



5. INSPECT UNDERDRIVE PLANETARY GEAR PRELOAD

- (a) Using SST and a torque wrench, measure the turning torque of underdrive planetary gear assembly while rotating the torque wrench at 60 rpm.
SST 09387-00050
Torque: Turning torque at 60 rpm
0.10 to 4.41 N*m (1.0 to 45 kgf*cm, 0.9 to 39 in.*lbf)
HINT:
 Use a torque wrench with a fulcrum length of 160 mm (6.30 in.)



- (b) Using a pin punch and a hammer, stake the lock nut.

NOTICE:

Make sure that there are no cracks on the nut.